

## Hypercom L5000 USB to RS232

### INTRODUCTION

These release notes provide version-specific information on L5000 USB to RS232

### MODULE RELEASE SUMMARY

Application	Hypercom L5000 USB to RS232
Version	L5000 Serial Driver v1.0.5
File Name	Hypercom_L5xxx Serial_Installer.exe
Platform	Windows XP 32bit Windows 7 32bit Windows 7 64bit
Release Date	April 13, 2011
Associated Documents	L5000 USB to RS232 Install Guide

### New Features in this Version:

Description	
1	New Driver supports for the L5xxx and operating systems

### Changes in this Version:

Description	

### Fixes in this Version:

Descriptions	

### KNOWN ISSUES

Descriptions	
1	For the USB host and gadget modules to function normally, they must be loaded in correct sequence.

### LIMITATIONS:

Descriptions	
1	Setting of COM port can only be done after device has been installed
2	Installer runs only on Windows XP 32-bit
3	Driver is unsigned. Class co-installer is used with HypHookLib library to suppress "Found New Hardware" Wizard dialogs